

# CONOTEC

CONOTEC CO., LTD.  
DIGITAL TEMPERATURE CONTROLLER



DSFOX - TC10

Instruction Manual



- Keep this product away from any place that generates strong alkaline or acid substances. Use a separate pipe.
- Do not sprinkle water onto this product for cleaning when installing it in the kitchen.
- Do not install this product in any place where the temperature/humidity ratings are exceeded
- The sensor cable should not be cut or cracked..
- Keep the sensor cable away from a signal cable, a power cable or a load cable. Use a separate pipe.
- Keep in mind that the follow-up service will not be available if this product has been arbitrarily disassembled and modified
- ⚠ symbol on the terminal wiring diagram indicates a safety statement that alerts a warning or caution.
- Do not use this product near any device generating strong high-frequency noise (e.g. high-frequency welding machine high-frequency sewing machine, high-frequency radio, large-capacity SCR controller, etc.).
- Using this product in any method other than those specified by the manufacturer may lead an injury or a property damage
- The product is not a toy. Keep it away from children.
- The product should be installed only by an expert or a qualified person.
- The company will not be liable for any damage caused by the violation of the above warnings and cautions or by a consumer's fault

### ⚠ Danger

Caution: Risk of electric shock

- Electric shock – Do not touch the AC terminal while the current is flowing. It may cause an electric shock.
- Disconnect the input power before checking the input power.

## 02 Model Types

Model	Sensor	Control Type	Temperature Range	Power	Function
DSFOX-TC10	CA(K)	Relay Contact (1EA)	Celsius : ~ 50.0 ℃ ~ + 400.0 ℃ Fahrenheit : ~ 58 °F ~ + 752 °F	100~240 VAC 50/60Hz	Temperature control


## 03 Components



- 1 OUT output display   2 SET switch   3 Back Switch  
4 Up Switch   5 Down Switch   6 Temperature unit

## 04 Terminal wiring diagram

[ DSFOX - TC10 ]



- ※ Output : 250VAC 2A: A power relay or a magnet must be used.
- ※ Be careful that any load over the contact capacity may cause contact fusion, contact defect, relay damage or others.

## 05 Setting process

### Setting Method

Name	Image	Description
Set key	SET	Entry into or return to the settings page Selection and saving of data values
Back switch	●	Go to the previous menu when setting up a program
Up/Down key	▲ / ▼	Increment/decrement of the selected menu data


### ■ Chance of the temperature output's set temperature (temperature setting)

- If you press the **SET** key once, the setting will blink and be displayed.
- Increase or decrease the setting with the **▲** or **▼** key


### ■ Installer mode settings (Program settings)

- Press the **SET** key for at least 5 seconds to enter into the installer mode.
- Configure the program based on the temperature program configuration diagram.
- Press **●** key for Enter the previous setting menu (\*Program setting mode only)

### Temperature Setting



### Program Setting (The value of each item is the factory setting.)




## 06 Function details

- Unit** : Change of the temperature unit
- *C* (temperature displayed in Celsius)
  - *F* (temperature displayed in Fahrenheit)


△ Note : If you change the *Unit* while the product is running, all the settings except for the *Unit* will be initialized to factory settings. Please reset all the settings.

- Typ** : Output function option
- Cooling(*Cool*) or Heating(*Heat*)

- dF** : Deviation temperature setting
- For on/off control, there should be a certain interval between on and off.
  - A relay or other output contacts may be quickly damaged or experience hunting (electricity generation, chattering,etc.) due to an external noise if the on/off function is used too frequently.
  - Different temperature is set to prevent such phenomenon and protect relevant contacts.
- Ex1) Set temperature : 20.0℃, *Typ* : *Cool*, *dF* : 5.0      - Ex2) Set temperature : 20.0℃, *Typ* : *Heat*, *dF* : 5.0



- dLt** : Output delay time setting
- Used if the on/off function of a control target is used too frequently (freezer,compressor,etc.)
  - Protects running machine from momentary outage or power re-connection.
- Ex) When is the output on for the following conditions:  
set temperature (10.0℃); *dLt*(00.30), *dF*(5.0℃)?



- Cor** : Correction of the current temperature
- Used to correct the current temperature based on the reference temperature (e.g. mercury thermomrter, existing thermometer, thermostat,etc.) when there is an input error by an external sensor even though the product itself does not have any problem.
- Ex) Actual temperature : 10.0℃ → **Cor** Modification of 0.0 to -2.0  
Display window : 12.0℃ → Displayed as 10.0 (current temperature modified)


- Addr** : Communications address setting
- An addres from 1 to 99 should be specified for RS485 communications

- bPS** : Baudrate setting
- 1200BPS / 2400BPS / 4800BPS / 9600BPS / 19200BPS

- Cdt** : Communication data type setting
- Change the communication data format to Float type or Integer type.
  - Float (*FL*) and Integer (*IN*) selections.

- LoL** : Locking of the setting
- Safety function intended to prevent anyone other than the main user from changing the settings
  - If set at *on* : All the settings expect for the set temperature will be locked.
  - If set at *off* : All the settings will be unlocked.

## 07 Diemension and panel hole sizes



## 08 Easy error diagnosis instructions

✖ If an error is displayed while the product is running

- **Err1** : It is case where the product was subject to a strong external noise and internal data memories have been damaged  
In this case, contact us for product service.
- Although this controller was designed to withstand a certain level of external noise, it is not supposed to withstand all levels of noise.
- If the product is subject to a noise greater than 2KV, it could be internally damaged.
- If **OE** (open error) or **SE** (short error) is displayed, there is something wrong with a sensor. Please check the sensor.
- If **OK** is displayed, settings have been saved.
- A text such as **LoL** (lock) indicates that the product is in the lock mode.
- If **Err10** (product name) is displayed, it refers to a model name.

✖ The above specifications may be changed without any notice for performance enhancement. Please make yourself fully familiar with and follow the above precautions.

■ Warranty period: One year from the date of purchase

■ Address : (Street address) 56, Ballyongsandan 1-rp, Jangan-eup, Gijang-gun, Busan, ROK  
(Land-lot address) 901-1, Ballyong-ri, Jangan-eup, Gijang-gun, Busan, ROK (46034)

- Product service : 070-7815-8289
- Customer service : 051-819-0425 ~ 0427
- FAX : 051-819-4562
- Email : conotec@conotec.co.kr
- SNS : Facebook, Instagram, Twitter, YouTube▶ 'Search for 'Conotec'
- Website : www.conotec.co.kr

◆ Installation precautions

■ This device should be connected to a protective earth terminal and a power supply in order to prevent an electric shock.

■ Do not block the air outlet.

◆ Operation precautions

✖ An operating environment of this device is as follows.

■ Ambient temperature : 0 ~ 60℃ ■ Ambient humidity : 80%RH or less

■ Indoor uses only

■ Pollution class 2

■ Altitude under 2000m

■ Installation category : II

■ This device should be laid out in a way that its power cord is easy to handle.

■ Using this product in any method other than those specified by the manufacturer may damage its protection function

■ Major products and development

- Temperature/humidity controller
- Counter and timer controller
- Current and voltage panel meter
- Temperature/humidity indicator
- Oven controller
- CO2 controller
- PID controller
- Unit cooler controller
- Heat pump controller
- Chiller controller
- Thermo-hygrostat controller
- Short message alarm
- Temperature/humidity transmitter
- Smartphone app and monitoring system

✖ This manual was prepared in the Naver Nanum fonts.